



FRONTIER

NISSAN

ARB DELUXE BULL BARS & WINCH BARS

<u>Year</u>	<u>Type</u>	<u>Features</u>	<u>Winches</u>	<u>Part No.</u>
1997-00	Winch Bar	Recessed Indicators, Tow Points, Black	HS9500, XD9000, M8000, M6000	3438110

IPF LIGHTS & LIGHTING ACCESSORIES

<u>Year</u>	<u>Type</u>	<u>Recommended Lighting</u>
1997-00	3438110	800XSD, 900XS, 900HID, 930S/R, 960 S/R, 868CS, 968CS, J-01

SAFARI SNORKELS

<u>Year</u>	<u>Recommended Snorkel</u>	<u>Part No.</u>
N/A	N/A	N/A

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
1996-00	Front	Stock/Light Load				N/A ¹
			Shock			N58 ²
Rear	Medium Load (0lbs to GVW)		Spring	1.25"	2	CS030R
			Shock		2	N59
Rear	Heavy Constant (880lbs to GVW)		Spring	1.25"	2	OMENN12
			Shock		2	N59
Installation	Leaf Spring Bushing Kit	U Bolts			2	OMESB81 ²
					4	OMEU63
					1	OMESD35
Optional	Rear Extra Leaf					D18XL ³

¹ Adjust front torsion bar for additional height after installing rear springs. Set ride height to 1/3 upper bump stop clearance and 2/3 lower bump stop clearance.

² It may be necessary to slightly increase the clearance in the front wishbone to allow shock absorber to fit. Do not modify shock absorber.

³ Extra Leaf can be fitted for heavier constant load carrying ability.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1986 On	Front	R180A, 4 Cyl.	27.8 (1.09")	27	ALL	N/A
		R200A, 6 Cyl.	30.4 (1.20")	29	ALL	RD107
1986 On	Rear	H233B, 31 spline, 6 Cyl.	32.4 (1.20")	31	ALL	RD09 ²
		H233B, 33 spline, 6 Cyl.	33.3 (1.31")	33	ALL	RD24 ²
1986-97	Rear	C200, 29 spline, 4 Cyl.	30.4 (1.20")	29	ALL	RD107 ^{1,2}
2002 On	Rear	C200, 31 spline,	32.0 (1.26")	31	ALL	RD106

¹ Only suitable for differentials with 12mm crown wheel bolts.

² Refer to dealer or check spline count to determine axle type.



PATHFINDER

NISSAN

ARB DELUXE BULL BARS & WINCH BARS

Year	Type	Features	Winches	Part No.
2000-02	Sahara Bar	Airbag Approved, Recessed Fog Lamp Provision ¹ , Urethane Buffers, Tow Points ² , Grev	HS9500, XD9000, M8000, M6000	3938020
1987-95	Winch Bar	Recessed Indicators, Tow Points, Black	XD9000, M8000, M6000	3438040

¹ Optional on this model - ARB part no. 9381FCK

² Utilizes original equipment tow points.

IPF LIGHTS & LIGHTING ACCESSORIES

Year	Type	Recommended Lighting
2000-02	3938020	800XSD, 900XS, 900HID, 930S/R, 960 S/R, 868CS, 968CS, J-01
1987-95	3438040	800XSD, 900XS, 900HID, 930S/R, 960 S/R, 868CS, 968CS, J-01

SAFARI SNORKELS

Year	Recommended Snorkel	Part No.
1986-97	D21, 2.7L, Diesel, Left Side Mount Refer to www.safari4x4.com.au for details.	SS700HF

OLD MAN EMU SUSPENSION PRODUCTS

Model	Location	Description	Type	Lift	Quantity	Part No.	
2005-06 R51 Models	Front	Stock/Light Load (0-90lbs)	Spring	1.0"	2	OME607	
			Shock		2	N183S	
	Rear	Medium Load (90lbs-220lbs)		Spring	1.0"	2	OME608
				Shock		2	N183S
		Medium Load (0lbs to GVW)		Spring	1.0"	2	OME609
				Shock		2	N184
		Constant Heavy Load (440lbs+)		Spring	1.0"	2	OME610
				Shock		2	N184
	**OE plastic stone shield must be refitted onto N183S and a 4-wheel alignment must be carried out after fitment of OME suspension.						
	1996-04 R50 Models	Front	Stock/Light Load (0-60lbs)	Spring	.50"	2	OME921
Right Side			Shock		1	N143S	
Left Side			Shock		1	N144S	
Front		Medium Load (50-110lbs)		Spring	.50"	2	OME923
				Shock		1	N143S
		Left Side	Shock		1	N144S	
Front		Heavy Load (110-220lbs)		Spring	.50"	2	OME928
				Shock		1	N143S
		Left Side	Shock		1	N144S	
Rear		Medium Load (0lbs to GVW)	Spring	.50"	2	OME922	
		Medium Load (to 1/1999)	Shock		2	*N61/N61C	
		Medium Load to (2/1999)	Shock		2	*N104/N104C	
1987-95		Front	Stock/Light Load (0-110lbs)	Spring			N/A ¹
				Shock		2	N26F
	Rear	Medium Load (0lbs to GVW)		Spring	.75"	2	OME920
				Shock		2	*N42/N89
	Installation	Steering Damper				1	OMESD35

¹ Adjust front torsion bar for additional height after installing rear springs. Set ride height to 1/3 upper bump stop clearance and 2/3 lower bump stop clearance.

² It may be necessary to slightly increase the clearance in the front wishbone to allow shock absorber to fit. Do not modify shock absorber.

*Firmer shock.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1987 On	Front	R180A, 4 Cyl.	27.8 (1.09")	27	ALL	N/A
		R200A, 6 Cyl.	30.4 (1.20")	29	ALL	RD107
1987 On	Rear	H233B, 31 spline, 6 Cyl.	32.4 (1.20")	31	ALL	RD09 ²
		H233B, 33 spline, 6 Cyl.	33.3 (1.31")	33	ALL	RD24 ²
1986-97	Rear	C200, 29 spline, 4 Cyl.	30.4 (1.20")	29	ALL	RD107 ^{1,2}

¹ Only suitable for differentials with 12mm crown wheel bolts.

² **Refer to dealer or check spline count to determine axle type.**



PATROL GQ

NISSAN

ARB DELUXE BULL BARS & WINCH BARS

Year	Type	Features	Winches	Part No.
To 1992	Bull Bar			3216080 ¹
1992 On	Bull Bar			3216050 ²
All	Winch Bar		10000lb, 9000lb & 8000lb	3416110

¹ Coil Spring Models

² Leaf Spring Models

IPF LIGHTS & LIGHTING ACCESSORIES

Year	Type	Recommended Lighting
All	All	800XSD, 900XS

SAFARI SNORKELS

Year	Recommended Snorkel	Part No.
1988 On	TD42, 4.2L, Diesel, Left hand mount	SS10HFHPC
	TB42E, 4.2L, Gas, Left hand mount	SS10HFVPC

Refer to www.safari4x4.com.au for details.

OLD MAN EMU SUSPENSION PRODUCTS

Model	Location	Description	Type	Lift	Quantity	Part No.
GQ Y60	Front	Light Load to 110lbs	Spring	2"	2	OME975
LWB, 4.2L			Shock		2	N23F
Diesel & Gas	Installation	Steering Damper			1	OMESD36 ⁵
		Steering Damper			1	OMESD34 ⁵
		Caster Kit			1	OMECA77B ²
		Trim Packer				OMEGQPF05 ¹
		Trim Packer				OMEGQPF10 ¹
	Front	Load 110 - 240lbs	Spring	2"	2	OME976
			Shock		2	*N21/N23F
	Installation	Steering Damper			1	OMESD36 ⁵
		Steering Damper			1	OMESD34 ⁵
		Caster Kit			1	OMECA77B ²
		Trim Packer				OMEGQPF05 ¹
		Trim Packer				OMEGQPF10 ¹
	Front	Low Height to 110lbs	Spring	1"	2	OME974
			Shock		2	N21
	Installation	Steering Damper			1	OMESD36 ⁵
		Steering Damper			1	OMESD34 ⁵
		Caster Kit			1	OMECA77B ²
		Trim Packer				OMEGQPF05 ¹
		Trim Packer				OMEGQPF10 ¹
ALL	Rear	Light to Medium Loads	Spring	1.5"	2	OMEQ02C
			Shock		2	N22F
	Installation	Trim Packer				OMEGQPF05 ¹
		Trim Packer				OMEGQPF10 ¹
ALL	Rear	Medium Load to GVW	Spring	2"	2	OMEGQ2AM
			Shock		2	N22F

OLD MAN EMU SUSPENSION PRODUCTS

Model	Location	Description	Type	Lift	Quantity	Part No.		
ALL	Installation	Gearbox Packer Kit			1	GQGK01 ³		
		Trim Packer				OMEGQPR05 ¹		
		Trim Packer				OMEGQPR10 ¹		
	Rear	Constant 440lbs to GVW	Spring	2"	2	OMEGQ02J		
			Shock		2	*N29/N22F		
	Installation	Gearbox Packer Kit				1	GQGK01 ³	
		Trim Packer					OMEGQPR05 ¹	
		Trim Packer					OMEGQPR10 ¹	
	GQ Y60, 3L Petrol & 2.8 Turbo Diesel, SWB & LWB	Front	Light Load to 110lbs	Spring	2"	2	OME974	
				Shock		2	N23F	
		Installation	Steering Damper Caster Kit Trim Packer Trim Packer				1	OMESD36
							1	OMECA77B ²
							OMEGQPF05 ¹	
							OMEGQPF10 ¹	
Front		Load 110 - 240lbs	Spring	2"	2	OME972		
			Shock		2	*N21/N23F		
Installation		Steering Damper Caster Kit Trim Packer Trim Packer				1	OMESD36	
						1	OMECA77B ²	
							OMEGQPF05 ¹	
							OMEGQPF10 ¹	
Rear		Light to Medium Load	Spring	1"	2	OMEGQ02CM		
			Shock		2	N22F		
Installation		Trim Packer Trim Packer					OMEGQPR05 ¹	
							OMEGQPR10 ¹	
Rear		Medium Load to GVW	Spring	1.5"	2	OMEGQ02C		
			Shock		2	N22F		
Installation		Trim Packer Trim Packer Gearbox Packer Kit					OMEGQPR05 ¹	
							OMEGQPR10 ¹	
						1	GQGK01 ³	
Rear		Constant 440lbs to GVW	Spring	2"	2	OMEGQ02J		
			Shock		2	*N29/N22F		
Installation		Trim Packer Trim Packer Gearbox Packer Kit					OMEGQPR05 ¹	
						OMEGQPR10 ¹		
					1	GQGK01 ³		

¹ Coil trim packers may be required to trim vehicle to a maximum of .59" per coil. Packers may be installed on the top on rear coils and to the bottom on front coils. Part No. OMEGQPF10 & OMEGQPR10 = .39". Part No. OMEGQPR10 & OMEGQPR05 = .20"

² OMECA77B caster kit will increase caster angle by 2°. Caster angle will be affected when raising vehicle. Check Manufacturer's specifications to determine if OMECA77B is required.

³ Gearbox Packer kit is designed to space down the gearbox cross member from the chassis to reduce tail shaft flange angle thereby reducing driveline vibration.

⁵ OMESD36 fits 8/89 models onwards. OMESD34 fits pre 8/89 models.

¹ Coil trim packers may be required to trim vehicle to a maximum of .59" per coil. Packers may be installed on the top on rear coils and to the bottom on front coils. Part No. OMEGQPF10 & OMEGQPR10 = .39". Part No. OMEGQPR10 & OMEGQPR05 = .20"

² OMECA77B caster kit will increase caster angle by 2°. Caster angle will be affected when raising vehicle. Check Manufacturer's specifications to determine if OMECA77B is required.

³ Gearbox Packer kit is designed to space down the gearbox cross member from the chassis to reduce tail shaft flange angle thereby reducing driveline vibration.

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
GQ Y60 All 4.2 SWB	Front	Light Load to 100lbs	Spring	2"	2	OME975
			Shock		2	N23F
	Installation	Trim Packer				OMEGQPF05 ¹
		Trim Packer				OMEGQPF10 ¹
		Steering Damper			1	OMESD36 ⁵
		Steering Damper			1	OMESD34 ⁵
		Caster Kit			1	OMECA77B ²
	Front	Heavy Load 110 to 240lbs	Spring	2"	2	OME976
			Shock		2	N22F
	Installation	Trim Packer				OMEGQPF05 ¹
		Trim Packer				OMEGQPF10 ¹
		Caster Kit			1	OMECA77B ²
	Front	Low Height 110lbs Load	Spring	1"	2	OME974
			Shock		2	*N21/N23F
Installation	Trim Packer				OMEGQPF05 ¹	
	Trim Packer				OMEGQPF10 ¹	
	Steering Damper			1	OMESD36 ⁵	
	Steering Damper			1	OMESD34 ⁵	
	Caster Kit			1	OMECA77B ²	
Front	Light to Medium Load	Spring	1"	2	OME974	
		Shock		2	*N21/N23F	
Installation	Trim Packer				OMEGQPF05 ¹	
	Trim Packer				OMEGQPF10 ¹	
	Steering Damper			1	OMESD36 ⁵	
	Steering Damper			1	OMESD34 ⁵	
	Caster Kit			1	OMECA77B ²	
Rear	Light to Medium Load	Spring	1"	2	OMEQ02CM	
		Shock		2	N22F	
Installation	Trim Packer				OMEGQPR05 ¹	
	Trim Packer				OMEGQPR10 ¹	
	Gearbox Packer Kit			1	GQGK01 ³	
Rear	Medium Load to GVW	Spring	1.5"	2	OMEQ02CM	
		Shock		2	N22F	
Installation	Trim Packer				OMEGQPR05 ¹	
	Trim Packer				OMEGQPR10 ¹	
	Gearbox Packer Kit			1	GQGK01 ³	
Rear	Constant 440lbs to GVW	Spring	1.5"	2	OMEQ02G	
		Shock		2	N22F	
Installation	Trim Packer				OMEGQPR05 ¹	
	Trim Packer				OMEGQPR10 ¹	
	Gearbox Packer Kit			1	GQGK01 ³	

¹ Coil trim packers may be required to trim vehicle to a maximum of .59" per coil. Packers may be installed on the top on rear coils and to the bottom on front coils. Part No. OMEGQPF10 & OMEGQPR10 = .39". Part No. OMEGQPR10 & OMEGQPR05 = .20"

² OMECA77B caster kit will increase caster angle by 2°. Caster angle will be affected when raising vehicle. Check Manufacturer's specifications to determine if OMECA77B is required.

³ Gearbox Packer kit is designed to space down the gearbox cross member from the chassis to reduce tail shaft flange angle thereby reducing driveline vibration.

⁵ OMESD36 fits 8/89 models onwards. OMESD34 fits pre 8/89 models.

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>	
GQ Y60 Cab Chassis Coil	Front	Light Load to 110lbs	Spring	2"	2	OME975	
			Shock		2	N23F	
Spring Models	Installation	Trim Packer				OMEGQPF05 ¹	
		Trim Packer				OMEGQPF10 ¹	
		Steering Damper			1	OMESD36	
		Caster Kit			1	OMECA77B ²	
	Front	Heavy Load 110 to 240lbs	Spring	2"	2	OME976	
			Shock		2	N21	
	Installation		Trim Packer				OMEGQPF05 ¹
			Trim Packer				OMEGQPF10 ¹
			Steering Damper			1	OMESD36
			Caster Kit			1	OMECA77B ²
Rear	Medium Load to GVW	Spring	1.5"	2	OMEGQ02C		
		Shock		2	N22F		
Installation		Trim Packer				OMEGQPR05 ¹	
		Trim Packer				OMEGQPR10 ¹	
		Gearbox Packer Kit			1	GQGK01 ³	
Rear	Constant 440lbs to GVW	Spring	2"	2	OMEGQ02J		
		Shock		2	*N29/N22F		
Installation		Trim Packer				OMEGQPR05 ¹	
		Trim Packer				OMEGQPR10 ¹	
		Gearbox Packer Kit			1	GQGK01 ³	
¹ Coil trim packers may be required to trim vehicle to a maximum of .59" per coil. Packers may be installed on the top on rear coils and to the bottom on front coils. Part No. OMEGQPF10 & OMEGQPR10 = .39". Part No. OMEGQPR10 & OMEGQPR05 = .20"							
² OMECA77B caster kit will increase caster angle by 2°. Caster angle will be affected when raising vehicle. Check Manufacturer's specifications to determine if OMECA77B is required.							
³ Gearbox Packer kit is designed to space down the gearbox cross member from the chassis to reduce tail shaft flange angle thereby reducing driveline vibration.							
Patrol GQ Y60 UTE & Cab Chassis	Front	Light Load to 110lbs	Spring	1"	2	OME110 ¹	
			Shock		2	N28	
Leaf Spring Models	Installation	Spring Bush			2	OMESB1	
		Greasable Shackle			1	OMEGS2	
		Greasable Shackle			1	OMEGP2	
		Steering Damper			1	OMESD22	
Front	Heavy Load 110 to 240lbs	Spring	1"	2	OME11 ¹		
		Shock		2	N28		
Installation		Spring Bush			2	OMESB1	
		Greasable Shackle			1	OMEGS2	
		Greasable Shackle			1	OMEGP2	
		Steering Damper			1	OMESD22	
Rear	Medium Load to GVW	Spring	1.75"	2	OME6A/B		
		Shock		2	N25		
Installation		Spring Bush			2	OMESB64	
		Greasable Shackle			1	OMEGS1	
		Greasable Shackle			1	OMEGP2	
		U Bolts			4	OMEU58B	
		Anti Inversion Kit			1	FK08 ²	
Rear	Constant 880lbs to GVW	Spring	1.75"	2	OME61A/B		
		Shock		2	N25		
Installation		Spring Bush			2	OMESB64	
		Greasable Shackle			1	OMEGS1	
		Greasable Shackle			1	OMEGP2	

OLD MAN EMU SUSPENSION PRODUCTS (CONTINUED)

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
		U Bolts			4	OMEU58B
		Anti Inversion Kit			1	FK08 ²
		¹ CBS02 x 2 center bolt spacers required for front spring fitment.				
		² FK08 Anti Inversion kit is mandatory fitment if greasable shackles are not fitted.				

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1988-98	Front	H233B	32 (1.26")	31	All	RD78A
	Rear	H233B, rear disc brakes	33.3 (1.31")	33	All	RD17
		H233B, rear drum brakes	33.3 (1.31")	33	All	RD24
		H260, leaf sprung cab chassis & utility	38.4 (1.51")	37	All	RD70
		¹ Only suitable for differentials with 12mm ring gear bolts.				
		² Refer to dealer or check spline count to determine axle type.				

ARB ROOF RACKS

<u>Models</u>	<u>Recommended Roof Racks</u>	<u>Part No.</u>
GQ LWB and SWB	87x49" Rack with Mesh Floor	3800010M
SWB	87x49" Rack without Mesh Floor	3800010
	87x49" Touring Rack for Roof Top Tent	3800200
	Fitting Kit for 87x49" racks	3700050
	73x49" With Mesh Floor	3800020M
	73x49" Without Mesh Floor	3800020
	Fitting Kit for 73x49" racks	3700050
	43x49" With Mesh Floor	3800030M
	Fitting Kit for 43x49" racks	3700060
	Wind Deflector for 49" wide Roof Rack	3700310
	Hi-lift Jack and Shovel holder for ARB Roof Rack	K6202

**use 43x49" rack for SWB Vehicles with Steel Roof



PATROL MQ

NISSAN

ARB DELUXE BULL BARS & WINCH BARS

<u>Year</u>	<u>Type</u>	<u>Features</u>	<u>Winches</u>	<u>Part No.</u>
All	Winch Bar		8000lb	3418010

IPF LIGHTS & LIGHTING ACCESSORIES

<u>Year</u>	<u>Type</u>	<u>Recommended Lighting</u>
All	Winch Bar	800MSR, 900MSR, 900XSS, 900XSD

SAFARI SNORKELS

<u>Year</u>	<u>Recommended Snorkel</u>	<u>Part No.</u>
1980-88	SD33, 3.3L, Diesel, Left side mount	SS11HF
	SD33T turbo, 3.3L, Diesel, Left side mount	SS11HF

Refer to www.safari4x4.com.au for details.

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
MQ M60 All	Front	Light Load to 110lbs	Spring	1.5"	2	CS010FA/B ¹
Petrol		Early	Shock		2	*N47/N96
Models		Late	Shock		2	N49
	Installation	Spring Bush			2	OMESB28 ²
		Spring Bush			2	OMESB29 ²
		Spring Bush			2	OMESB31 ²
		Spring Bush			2	OMESB29 ²
		U Bolt			2	OMEU56
		U Bolt			2	OMEU57
		Steering Damper			1	OMESD22
	Front	Heavy Load 110lbs to 240lbs	Spring	1.5"	2	CS011FA/B ¹
		Early	Shock		2	*N47/N96
		Late	Shock		2	N49
	Installation	Spring Bush			2	OMESB28 ²
		Spring Bush			2	OMESB29 ²
		Spring Bush			2	OMESB31 ²
		Spring Bush			2	OMESB29 ²
		U Bolt			2	OMEU56
		U Bolt			2	OMEU57
		Steering Damper			1	OMESD22
MQ M60 All	Front	Light Load to 110lbs	Spring	1"	2	CS010FA/B ¹
Diesel		Early	Shock		2	*N47/N96
Models		Late	Shock		2	N49
	Installation	Spring Bush			2	OMESB28 ²
		Spring Bush			2	OMESB29 ²
		Spring Bush			2	OMESB31 ²
		Spring Bush			2	OMESB29 ²
		U Bolt			2	OMEU56
		U Bolt			2	OMEU57
	Front	Heavy Load 110lbs to 240lbs	Spring	1"	2	CS011FA/B ¹
		Early	Shock		2	N47
		Late	Shock		2	N49

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
	Installation	Spring Bush			2	OMESB28 ²
		Spring Bush			2	OMESB29 ²
		Spring Bush			2	OMESB31 ²
		Spring Bush			2	OMESB29 ²
		U Bolt			2	OMEU56
		U Bolt			2	OMEU57
		Steering Damper			1	OMESD22
ALL	Rear	Medium Load to GVW	Spring	2"	2	CS011R
			Shock		2	N97
	Installation	Spring Bush			2	OMESB2 ³
		Spring Bush			2	OMESB29 ³
		U Bolt			4	OMEU58
	Rear	Constant Load 440lbs to GVW	Spring	2"	2	CS012R
			Shock		2	*N48/N97
	Installation	Spring Bush			2	OMESB2 ³
		Spring Bush			2	OMESB29 ³
		U Bolt			4	OMEU58

¹ Models with P40 4L engine require CS011FA/B spring. Individual vehicles fitted with A/B fitment may experience a pronounced trimming problem to driver side. In these cases fitment of an XL leaf to the driver side will correct the problem

² Front spring bushes: Early model (round headlight) require OMESB28 & OMESB29. Late model (square headlight) require OMESB31 & OMESB29. OME bush kits must be used to enable springs to be fitted.

³ OME bush kits must be used to enable springs to be fitted.

⁴ Front U bolt: OMEU56 fits to driver side & OMEU57 fits to passenger side.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1979-88	Front	C200	30.4 (1.20")	29	All	RD107
	Rear	H233	32.0 (1.26")	31	All	RD04
		H260	38.4 (1.51")	37	All	RD70

¹ Only suitable for differentials with 12mm crown wheel bolts.

² Refer to dealer or check spline count to determine axle type.

ARB ROOF RACKS

<u>Models</u>	<u>Recommended Roof Racks</u>	<u>Part No.</u>
MQ	87x49" Rack with Mesh Floor	3800010M
	87x49" Rack without Mesh Floor	3800010
	87x49" Touring Rack for Roof Top Tent	3800200
	Fitting Kit for 87x49" racks	3700050
	73x49" With Mesh Floor	3800020M
	73x49" Without Mesh Floor	3800020
	Fitting Kit for 73x49" racks	3700050
	43x49" With Mesh Floor	3800030M
	Fitting Kit for 43x49" racks	3700060
	Wind Deflector for 49" wide Roof Rack	3700310
	Hi-lift Jack and Shovel holder for ARB Roof Rack	K6202

**use 43x49" rack for SWB Vehicles with Steel Roof



HARDBODY PICKUP D21

NISSAN

ARB DELUXE BULL BARS & WINCH BARS

<u>Year</u>	<u>Type</u>	<u>Features</u>	<u>Winches</u>	<u>Part No.</u>
1991-97	Winch Bar	Recessed Indicators, Tow Points, Black	XD9000, M8000, M6000	3438050

IPF LIGHTS & LIGHTING ACCESSORIES

<u>Year</u>	<u>Type</u>	<u>Recommended Lighting</u>
1991-97	3438050	800XSD, 900XS, 900HID, 930S/R, 960 S/R, 868CS, 968CS, J-01

SAFARI SNORKELS

<u>Year</u>	<u>Recommended Snorkel</u>	<u>Part No.</u>
1986-97	D21, 2.7L, Diesel, Left Side Mount Refer to www.safari4x4.com.au for details.	SS700HF

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>	
D21 Models	Front	Medium Load (over 110lbs)	Torsion		1	303008 ¹	
			Shock		2	N58 ²	
	Rear	Medium Load (0lbs to GVW)	Spring	1.0"	2	CS030R	
			Shock		2	N56	
			Spring	1.0"	Heavy Constant Load (800lbs)	2	CS031R
					Shock	2	N59
Installation		Steering Damper		1	OMESD35		
		Spring Bushing Kit		2	OMESB81		
		Ubolts		4	OMEU63		

¹ Adjust front torsion bar for additional height after installing rear springs. Set ride height to 1/3 upper bump stop clearance and 2/3 lower bump stop clearance.

² It may be necessary to slightly increase the clearance in the front wishbone to allow shock absorber to fit. Do not modify shock absorber.

*Firmer shock.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1986 On	Front	R180A, 4 Cyl.	27.8 (1.09")	27	ALL	N/A
		R200A, 6 Cyl.	30.4 (1.20")	29	ALL	RD107
1986 On	Rear	H233B, 31 spline, 6 Cyl.	32.4 (1.20")	31	ALL	RD09 ²
		H233B, 33 spline, 6 Cyl.	33.3 (1.31")	33	ALL	RD24 ²
1986-97	Rear	C200, 29 spline, 4 Cyl.	30.4 (1.20")	29	ALL	RD107 ^{1,2}

¹ Only suitable for differentials with 12mm crown wheel bolts.

² Refer to dealer or check spline count to determine axle type.



X-TRAIL

NISSAN

ARB DELUXE BULL BARS & WINCH BARS

Including Air Bag Equipped Models

<u>Year</u>	<u>Type</u>	<u>Features</u>	<u>Winches</u>	<u>Part No.</u>
2000-06	Nudge Bar	Driving light provision	N/A	3119010

IPF LIGHTS & LIGHTING ACCESSORIES

<u>Year</u>	<u>Recommended Lighting</u>
2000-06	800XSD, 900XS, 900HID, 960S/R, 868CS, 968CS, J-01

SAFARI SNORKELS

<u>Year</u>	<u>Recommended Snorkel</u>
N/A	N/A

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
2000-06	Front	Standard Load - Petrol Models	Spring	20mm	2	OME506
			Strut cartridge		2	NC161
	Standard Load - Diesel Models	Spring	20mm	2	OME507	
		Strut cartridge		2	NC161	
Rear	Standard Load - All Models	Spring	30mm	2	OME508	
		Strut cartridge		2	NC163	



NISSAN

ARB DELUXE BULL BARS & WINCH BARS

<u>Year</u>	<u>Type</u>	<u>Features</u>	<u>Winches</u>	<u>Part No.</u>
2000-04	Winch Bar	Recessed Indicators, Tow Points, Black	9.5XP, HS9500, XD9000, M8000	3438110

IPF LIGHTS & LIGHTING ACCESSORIES

<u>Year</u>	<u>Type</u>	<u>Recommended Lighting</u>
2000-04	3438110	800XSD, 900XS, 900HID, 930S/R, 960 S/R, 868CS, 968CS, J-01

SAFARI SNORKELS

<u>Year</u>	<u>Recommended Snorkel</u>	<u>Part No.</u>
N/A	N/A	N/A

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
N/A	N/A	N/A	N/A	N/A	N/A	N/A

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

<u>Year</u>	<u>Axle</u>	<u>Description</u>	<u>Shaft</u>	<u>Spline</u>	<u>Ratio</u>	<u>Part No.</u>
1986 On	Front	R180A, 4 Cyl.	27.8 (1.09")	27	ALL	N/A
		R200A, 6 Cyl.	30.4 (1.20")	29	ALL	RD107 ¹
2002 On	Rear	C200, 31 spline,	32.0 (1.26")	31	ALL	RD106 ¹

¹ Refer to dealer or check spline count to determine axle type.